

7100 Technology Drive West Melbourne, FL 32907 1-800-422-6281

Service Bulletin

BKSB-1022 Issue Date 12-19-05

Issue: Group Scan Programming – If groups are selected in the Group Scan list, but no channels are selected in the Channel Scan list; the keypad will appear unresponsive when Group Scan is enabled.

Affective Models: GPH5102XCMD portables

Recommended Action: Remove all groups from the Group Scan list if no channels are selected in the Channel Scan list.

Note: If the radio is unintentionally placed in this condition, simply adjust the squelch knob to the unquenched position. The keypad will then be responsive and "Group Scan" can be disabled.